

INSTRUCTIONS FOR THE ERECTION OF A MESH GAS CAGE

- 1 Erect the back panel into the upright position with the bolt holes facing forward. (Box frame facing inward, mesh facing out). See picture below.



- 2 Offer side panel up to the rear panel, align the bolt holes and fix with the bolts and nylok nuts provided. See picture below.



- 3 Repeat stage 2 to the opposite side.

- 4 Offer the front panel (door) to the side panels, align the bolt holes and fix with the bolts and nylok nuts provided. Ensure that the bolts are tight. See picture below.



- 5 Place the roof panel on top, align the bolt holes and fix with the bolts and nylok nuts provided. Check that all bolts are secure.

